

# Menzies Creek PA System (Training)


- [How to: Send a Pre-recorded Message \(Training\)](#)
- [How to: Live Page \(Training\)](#)

# How to: Send a Pre-recorded Message (Training)


Currently there is only 1 Audio Zone at Menzies Creek. Due to this zone control for the announcement is not required.



1. Firstly you can choose to delay in the announcement with the "**select pre-message delay**" field.



2. You can then select a message that you would like to broadcast in the "**Select Messages**" panel. Once the message is selected "**Start Messages**" is then selected to start the broadcast.



3. if you need to adjust the volume you can use the **Message** slider under **Audio Levels**

Message Playing Now:

00 - Train Approach Platform 1

Pre-Recorded Messages

Audio Levels

External Mic

Shure Mic

Message

XLR Input

0dB

0dB

-263dB

-6.36dB

Select Pre-Message Delay

None

1 Minute

2 Minutes

5 Minutes

10 Minutes

Select Messages

Select All

Clear All

00 - Train Approach Platform 1

Start Messages


Cancel

# How to: Live Page (Training)

## Live Paging

If no sound adjustment needs to be made please press and hold the button on the microphone and talk

1. If you need to change how loud the microphone is you can adjust it using the **Mics** slider



2. You can then push and hold the talk button on the microphone to talk and speak into the microphone.